



# Simple Start Guide



Don't forget! For your safety, Kozii will shut off *permanently* if too little water is used, or if Kozii is run dry. Follow filling instructions carefully, and check water level before each use.




Place Kozii on a flat, level surface and plug it in.



Add water.

About 1 and 3/4 cups of water are needed (14 fl oz/410ml).

- As you add water, allow about 5 seconds for the water to drain down into the reservoir.
- Kozii is full when the water level touches the word "FULL".
- Water level must always be above the word "EMPTY".



Insert bottle, bag or food jar and set the timer.

- Use the warming time chart on the back of this guide.
- Slightly more water may be added as needed to raise water level during warming.



When the time is up and the water level drops, the meal is ready.

- Gently swirl the meal around in its container for 30 seconds to ensure uniform temperature.
- Always test the meal temperature yourself before offering it to your child.

## Important things to know, for best results

- Water level will rise during warming. Do not move Kozii during warming.
- If the water level does not rise all the way to the overflow drain during warming, you may add slightly more water.
- Water must be added when the water level drops below the word "FULL" (about every 5-10 uses).
- It is **VERY IMPORTANT** to clean and de-scale Kozii regularly!
- See the instruction manual for complete use, care, and cleaning instructions.



## WARMING TIME CHART

Many factors affect the exact warming time for your child's meal. Please use this chart as a convenient starting point for determining the appropriate warming time for your specific meal type, container, and starting temperature. After only a couple of uses, you will learn exactly what the best warming times are for you. **Always test the meal temperature yourself before offering it to your child.**

**IMPORTANT: If Kozii feels warm around the base (from recent use), decrease warming time by 30 seconds.**

The timer may continue to tick for up to 30 seconds after Kozii has shut off. It is ok to remove the meal, as long as the water level has dropped.

### Approximate Warming Time (in minutes)

Bottle type	Plastic Bottle		Glass bottle		Bottle with liner		Breastmilk storage bag			Food jar	
	Room	Fridge	Room	Fridge	Room	Fridge	Room	Fridge	Freezer*	Room	Fridge
2oz (60ml)	3	4.5	2.5	4	2	2.5	2	3	5*	5	9
4oz (120ml)	3.5	5.5	3	4.5	2.5	3	2.5	3	7.5*	7	12
5oz (150ml)	3.5	6	4	5	2.5	3.25	3	3	9*	7.5	13
6oz (180ml)	3.5	7	5	6	3	3.5	3	3.5	9*	8	14
8oz (240ml)	4	8	5.5	7	3	4	3.5	4	10*	8.5	15
9oz (270ml)	4	9	6	8.5	3.5	4.5	na	na	na	9	15

\* For fastest, most uniform warming of frozen breastmilk bags: warm for 5 minutes, push remaining ice down to the bottom of the bag, then set timer for the remainder of the time.

Dear proud parents,

We hope you love your Kozii!

We would really love to hear from you.

Email us at [feedback@kiinde.com](mailto:feedback@kiinde.com) to let us know your thoughts on Kozii, and don't forget to visit us at [www.kiinde.com](http://www.kiinde.com) for more life-simplifying products.

Thank you!

The Kiinde team



Simple Start Guide